

## *Xtend & Climb telescopic ladder*

### Care and Maintenance Tips

- ❑ Never use WD40 or lubricants of that nature - they will attract dirt and dust which will clog
- ❑ Never leave your X&C out in the rain - moving components will clog up and rust
- ❑ To lubricate/clean your X&C use silicone based furniture wipes or spray, which removes dirt/residue and leaves a thin wax coating for smooth operation
- ❑ If your Xtend & Climb becomes excessively dirty – use a hose to remove dirt, wipe dry and apply silicone spray
- ❑ If your ladder is excessively wet, wipe dry & apply silicone wipes/spray
- ❑ Never use your X&C horizontally as a plank
- ❑ Never use your X&C as a vertical fire escape/RESQ ladder. They are not designed to be opened vertical downwards. The pins will not hold the downward force.
- ❑ Be careful not to press the vertical tubing of the stiles against concrete or other hard surfaces that may dent the aluminium. Always rest rubber bung at the top against vertical or horizontal surface

